

Folding Instructions

- Turn bike upside down.
- Fold opposite sides of Guard inwards and interlock.
- Insert the end pieces into the precut holes
- Feed the skewer through the Guard and secure

